


How can I add sensors?

In order to add sensors, you first need to enter the [device configuration menu](#), and go to the **Sensors** tab



After that in the Sensors field click the **Add** button

From:

<https://docs.bitrek.video/> - **Bitrek Video Wiki**

Permanent link:

<https://docs.bitrek.video/doku.php?id=en:sensorsadd>

Last update: **2024/04/18 12:26**