

How do I choose the type of storage?

First you need to connect **SSD** or **SD** module to your device (depends on the package of your device)



After that you need to go to [device configuration menu](#) and go to the **System/System Maintenance/Default Storage tab**

System maintenance



Default storage
microSD card

Storage file system format
EXT4 (for Linux)

Delete files policy

Storage used
97%

Event files count
500000

Files disk sharing
20% event files | 80% recorder video files

System reboot

Day of week
Daily

Hour
02

Minute
01

Ignition sensor

Sensor state
Disabled

Timeout, s
0

Ignition sensor state

0 - sensor disabled; 1..65000s - timeout

Camera power state configuration
Disabled

Timeout, s
0

Ignition ON - cams ON, ignition OFF - cams off

OFF timeout

Here you'll be able to choose the drive where your data will be stored: **SSD**, **SD** or **USB** drives

From:

<https://docs.bitrek.video/> - **Bitrek Video Wiki**

Permanent link:

<https://docs.bitrek.video/doku.php?id=en:storsagetype>

Last update: **2024/04/18 13:51**