

How do I turn video recorder on my DVR?

First you need to go to [device configuration menu](#) and go to the **Registrar/Video Recorder** tab



The screenshot shows a configuration page for a video recorder. At the top, it says "Video recorder" with a small square icon to the right. Below this, there are four sections, each for a camera (Camera 1, Camera 2, Camera 3, and Camera 4). Each section contains three input fields: "State" (set to "Disabled"), "Time interval (s)" (set to "300"), and "RTSP source" (set to "LOW").

Here you can configure the recorder mode, namely:

- Select **camera** which you want to turn on to the recorder (up to 4 cameras)
- Set **interval** of recording video in seconds (from 60 to 3600s)
- Select **Source RTSP stream** with which the video will be transmitted (1 stream - highest quality, 2 streams - lowest quality)

From:

<https://docs.bitrek.video/> - **Bitrek Video Wiki**

Permanent link:

<https://docs.bitrek.video/doku.php?id=en:viderecorder>

Last update: **2024/04/18 12:26**