Security

A section for viewing information about the device password, Read-only FTP user status, and changes

Figure 1 – Chapter security



Table 1 – Security parameters description

Parameter	Parameter description
DVR password	The device password is displayed when hovering over the field
Read-only FTP user	The name of Read-only FTP user
Password	Password of Read-only FTP user

To set the default settings, click the **Default** button. To save settings in NVR click **Save settings** button.

From:
https://docs.bitrek.video/ - **Bitrek Video Wiki**

Permanent link:
https://docs.bitrek.video/doku.php?id=en:security

Last update: **2025/08/31 23:18**