How can I add sensors?

In order to add sensors, you first need to enter the device configuration menu, and go to the **Sensors** tab



After that in the Sensors field click the **Add** button

From:
https://docs.bitrek.video/ - **Bitrek Video Wiki**

Permanent link:
https://docs.bitrek.video/doku.php?id=en:sensorsadd

Last update: **2025/08/31 23:18**