
How do I connect my device to the Internet via LAN?


First, you need to connect the LAN cable to a free port of the device and to the router




After that you need to go to device configuration, and go to the tab <u>Cameras/IPCameras</u>, where you need to remove the camera which was in the place where you connected the LAN if there is no such a camera you can skip this step



Then go to device configuration menu and go to the **Network/LAN** tab.





Here you can configure the device connection via LAN, namely:

- network type (static address or DHCP, we advise to choose a static address to avoid looking for the device on the network)
- IP address
- Gateway (IP of the router)
- Subnet mask
- Internal DHCP status

You can also perform a **network scan** and the device can automatically find the data you need to fill in

From:

https://docs.bitrek.video/ - Bitrek Video Wiki

Permanent link:

https://docs.bitrek.video/doku.php?id=en:lanconnect

Last update: 2025/08/31 23:18

https://docs.bitrek.video/ Printed on 2025/09/08 18:45